


Transporting Cylinders

Working safely with Gas Cylinders

Drive safely, arrive safely. There are some basic rules to follow when transporting cylinders:




No smoking.



Secure cylinders properly to prevent them from moving.



Check that cylinder valves are properly closed and that valve caps are fitted.




Go directly to your destination.



Ventilate your vehicle.



Do not leave cylinders inside the boot or in an unventilated place.



Disconnect regulators, hoses and torches etc.



Immediately unload at destinations, or if stopping for a longer time store in a ventilated place.

For more information please refer to www.bcga.co.uk

See the Bigger Picture with Maxx[®] weld process gases
www.airproducts.co.uk/maxx